

WARNING

POSITION THE CLAMPS AND BOLTS ON THE SLEEVE TO ENSURE THEY DO NOT INTERFERE WITH THE OIL PAN OR ANY OTHER PART OF THE VEHICLE